

Setting Black on Sony HDW-1800 HDCAM

- **PRESS: P1 (HOME) BUTTON**
- **PRESS: F9 (MENU) BUTTON**
- **USING MULTI-CONTROL DIAL, SCROLL TO MENU ITEM 710**
- **PRESS F6 TO SELECT**
- **PRESS: F3 AND F4 BUTTONS TO SELECT BLACK**
- **PRESS: F9 TO SET**
- **PRESS: ALT/DELETE BUTTON AND F1 AT THE SAME TIME TO ACTIVATE INTERNAL SIGNAL GENERATOR**
- **AFTER RECORDING BLACK, PRESS F1 (VIDEO IN) TO RETURN TO INPUT VIDEO**

