

# Changing Time-Code on the Panasonic AJ-HD1200AP

- SLIDE (LOCAL / REMOTE) SWITCH TO MENU
- USING THE **FF** BUTTON SCROLL DOWN AND SELECT **#500 TIME CODE**
- **PRESS: SEARCH / MODE** BUTTON
- USING THE **FF** BUTTON CHECK TO MAKE SURE  
#503 IS SET TO **PRE**  
#504 IS SET TO **REC**  
#507 IS SET TO **INT**
- USING **FF** BUTTON SCROLL TO **#530**
- **PRESS: PLAY** BUTTON TO CHANGE TIME-CODE
- **FF** WILL SWITCH TO NEXT # AND SO ON
- THEN PRESS **SET**