

Factory Reset

Sony SRW-5500 & SRW-5800

HDCAM HDCAM-SR

- **PRESS: (SET UP) BUTTON**
- **PRESS: F1 BUTTON (VTR BANK)**
- **USING THE ARROWS, SCROLL TO F (PRESET)**
- **SET F9 (COPY)**
- **Press SFT & F9 AT SAME TIME**