

# Setting Input Audio on the Sony SRW-5500 & SRW-5800 HDCAM HDCAM-SR

- **PRESS: HOME BUTTON**
- **PRESS: AUDIO BUTTON**
- **SET F1 TO (AUDIO IN)**
- **SET F9 SELECT AES/EBU OR SDI AUDIO**
- **SET F10 TO EXIT**
- **PRESS: RED RECORDS BUTTONS. SELECT CHANNEL TO BE RECORDED**