

# Setting Video Black on the Sony HDW-F500 HDCAM

- **Press: HOME BUTTON**
- **PRESS: SET UP BUTTON**
- **PRESS: F6** Button (VTR SET UP)
- **USING THE ARROWS: SCROLL DOWN TO MENU (T 02)**
- **PRESS: F7 (CHANGE DATA) MULTIPLE TIMES UNTIL SET TO (BLACK)**
- **PRESS: F10 TWICE TO SAVE AND EXIT**
- **PRESS: HOME BUTTON**