

Setting Video Black on the Sony SRW-5500 & Sony SRW-5800 HDCAM HDCAM-SR

- **PRESS: (SET UP) BUTTON**
- **PRESS: F6 BUTTON (VTR SET UP)**
- **USING THE ARROWS, SCROLL TO (OTHERS MENU) T 02**
- **SET F8 MULTIPLE TIMES UNTIL SET TO (BLACK)**
- **SET F10 TWICE TO SELECT MENU CHANGE AND EXIT**