Factory Reset on the Sony HDW-F500 HDCAM

- **Press: HOME** BUTTON
- **PRESS: SET UP** BUTTON
- **PRESS: F1** Button (VTR BANK)
- **USING THE ARROWS: SCROLL DOWN** TO **F** (PRESET)
- **PRESS: F9** (COPY)
- **PRESS: SFT & F9** SIMULTANEOUSLY
- **PRESS: HOME** BUTTON